

# Remote Setup for SRC 350 Gateway

## Setting up Gateway ID #

1. Point remote at Gateway.
2. Press & hold the SELECT button, then the MUTE button. Hold both buttons down together until the LED button illuminates, then release both buttons.
3. Press & release the B key. The LED button temporarily turns off. Releasing the key causes the LED button to light up again. You can now set the correct Gateway ID.
4. Enter the three-digit code assigned to your RG. (i.e. 007) To obtain your ID call 611.

## Setting up Remote for TV Stream

1. Press & hold the SELECT button, then the MUTE button. Hold both buttons down together until the LED button illuminates, then release both buttons.
2. Press & release the A key. The LED button temporarily turns off. Releasing the key causes the LED button to light up again. You can now set the correct Remote Control ID
3. Enter the single-digit Remote Control ID (1 for stream 1, 0 will set remote to IR)  
Channel 4 Stream 1  
Channel 7 Stream 2  
Channel 13 Stream 3
4. The LED button will blink three times and go out. The new Remote Control ID is stored in the device.

## Setting up remote for power and volume

1. Turn TV on.
2. Point remote at TV.
3. Press & hold the SELECT button, then the MUTE button. Hold both buttons down together until the LED button illuminates, then release both buttons.
4. Scroll up using the BLUE UP ARROW button until the TV turns off.
5. Press SELECT to lock in the TV code.
6. The LED button will blink three times and go out.



*Note: The SRC-350 is very similar in looks to the SRC-300 remote, with the exception of these buttons: **A** **B** **C** **D***